



Don't just purge...**ULTRA PURGE!**TM

Ultra Purge

Ready-to-use chemical purging compound

Please read carefully TDS-SDS before using Ultra Purge. If you don't have this document, you can download it from ultrapurge.com

Injection molding - High Temp - material change (same temperature)

This document is a general description on how to use Ultra Purge. Request your customized instructions by contacting your nearest sales office or local distributor.

- 1 Keep the barrel full of the previous production resin.
- 2 Add Ultra Purge using a quantity equivalent to 2 times the barrel capacity.
- 3 Load next material directly behind Ultra Purge.
- 4 Make shots until Ultra Purge is cleared from machine.
- 5 Adjust temps to desired settings.

Things to avoid with Ultra Purge :

- Load our product through heated feed line - Ultra Purge starts to melt at 80°C (176°F).
- Allow longer soaking time from what suggested.
- Use more than recommended quantities of Ultra Purge per cleaning.
- Increase temperatures if dealing with thermo sensitive resins or additives.
- Mould items that have a difficult ejection – the piece can be partially formed.

injection-molding-high-temp-material-change-(same-temperature)-v0.98b-eng.pdf